



# Items Supplied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support
- 2 M10 Spacers

# Application(s) >

Honda ACE 750 98-03

# Instruction Manual >

02-6115

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- 1. Remove your stock fender rail bolts.
- 2. Place the supplied spacers in the front recessed holes on the fender rails.
- 3. Install your Cobra saddlebag supports using the stock bolts (where the stock bolts were removed). The saddlebags should hang towards the rear and away from the motorcycle.
- 4. Torque bolts to factory specifications.
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A

07/03

Anything's Possible.

www.cobrausa.com

www.cobrausa.com



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

## Items Sunnlied >

- 1 Left Saddlebag Support
- 1 Right Saddlebag Support
- 2 M10 Spacers

### Annlication(s) >

Honda ACE 750 98-03

#### Instruction Manual >

02-6115

Your saddlebag supports will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new saddlebag supports.

- 1. Remove your stock fender rail bolts and washers.
- 2. Place the supplied spacers in the front recessed holes on the fender rails.
- 3. Install your Cobra saddlebag supports using the stock bolts (where the stock bolts were removed). The saddlebags should hang towards the rear and away from the motorcycle.
- 4. Torque bolts to factory specifications
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A 07/03