



Items Supplied >	Application(s) >	www.cobrausa.com
1 - CHROME DRIVE BELT GUARD 2 - M6x16mm BUTTONHEAD BOLTS	YAMAHA WARRIOR	2002 - 2010

## Instruction Manual >

06-0762

Your Drive Belt Guard will install in minutes using common tools. Read instructions carefully and completely before installing your new Cobra product.

- Remove stock drive belt guard and discard stock bolts.
- Align Cobra drive belt guard so the holes line up with the stock mounting locations and using the two supplied M6 bolts begin threading until snug. Do not tighten.
- Adjust the drive belt guard so that it does not make contact with the belt or any other components. After reaching the desired position fully tighten the bolts to their factory specifications.
- Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

04/09

Anything's Possible



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

## Items Sunnlied >

- 1 CHROME DRIVE BELT GUARD
- 2 M6x16mm BUTTONHEAD BOLTS

## www.cobrausa.com Annlication(s) > YAMAHA WARRIOR 2002 - 2010

## Instruction Manual >

06-0762

Your Drive Belt Guard will install in minutes using common tools. Read instructions carefully and completely before installing your new Cobra product.

- 1. Remove stock drive belt guard and discard stock bolts.
- Align Cobra drive belt guard so the holes line up with the stock mounting locations and using the two supplied M6 bolts begin threading until snug. Do not tighten.
- Adjust the drive belt guard so that it does not make contact with the belt or any other components. After reaching the desired position fully tighten the bolts to their factory specifications.
- Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.