

Items Supplied >

- 1 - Left Floor Board Assembly
- 1 - Right Floor Board Assembly
- 4 - Spacers
- 2 - Hex Bolt 10mm x 40mm

Application(s) >

Honda ACE 750 98-01

Instruction Manual >

06-1615 / 06-4115

Page 1 of 1

Your Floor Boards will install in just a few minutes using common tools. Read all instructions carefully and completely before installation.

1. Remove the left and right chrome foot peg mounts from the motorcycle.
2. Locate the left side floorboard assembly. The tall part of the floorboard mounting bracket faces the front of the motorcycle. Align the bolt already installed in the supplied floorboard mount with the lower mounting hole for the footpeg bracket and slide the bolt through the supplied spacer and finger tighten into the hole.
3. Install the stock bolt through the floorboard mount, spacer and into the upper footpeg mounting hole and tighten. Torque both bolts to factory specs.
4. Repeat the same procedure to install the right side floorboard assembly.
5. Check to make sure that everything is properly secured and that your rear brake and shift levers are properly adjusted prior to riding your motorcycle.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*