

## Items Supplied >

- 1 - Freeway Bar
- 2 - Aluminum Spacers
- 2 - Acorn Nuts
- 1 - Threaded Rod
- 2 - Spring Washers

## Application >

INTRUDER 1500 98-04  
BOULEVARD C90 05-09

## Instruction Manual >

01-1330/01-2330

Page 1 of 1

### Read all directions carefully before installing your Cobra freeway bar

1. Remove the rubber plugs in the frame on both sides just above the front cylinder head. Install the supplied spacers in the frame where the plugs were by rotating them so they seat all the way in.
2. Remove the front bolts from both floorboard mounts.
3. Mount the bottom of the freeway bar so that the slotted brackets mount to the floorboard brackets using the stock bolts.
4. Align the top of the freeway bar on each side with the spacers in step #1. Insert the supplied threaded rod through the freeway bar brackets and the spacers in the frame. Secure each side with a supplied washer and acorn nut.
5. Torque all hardware to factory torque specifications.
6. Check to make sure all hardware is tight and everything is in good working order before riding.

**Cobra Freeway Bars add style to your motorcycle. They are not designed to withstand a serious impact and may not protect you and/or your motorcycle in the event of a crash.**

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*