



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

### Items Supplied >

- 1 – FORMED RACK
- 4 – WASHERS
- 2 – M8 x 40mm BUTTONHEAD BOLTS
- 2 – M8 x 20mm BUTTONHEAD BOLTS

### Application(s) >

HONDA REBEL 250

1996-2015

### Instruction Manual >

02- 4106

Your formed rack will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new rack.

1. Remove the (2) left and (2) right M8 fender rail bolts/nuts. Discard bolts, but save (2) M8 nuts.
2. Install rack by inserting the longer supplied M8x45mm bolt through the front mounting hole of rack mount, one supplied washer, fender rail/frame and into the stock M8 nut retained from Step 1. Insert the shorter M8x20mm bolt through rear mounting hole of rack mount, one supplied washer and into fender rail/frame. **DO NOT TIGHTEN** at this time. Repeat on Right Side.
3. Align rack and tighten all bolts.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

09/10

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

### Items Supplied >

- 1 – FORMED RACK
- 4 – WASHERS
- 2 – M8 x 40mm BUTTONHEAD BOLTS
- 2 – M8 x 20mm BUTTONHEAD BOLTS

### Application(s) >

HONDA REBEL 250 1996-2015

### Instruction Manual >

02- 4106

Your formed rack will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new rack.

1. Remove the (2) left and (2) right M8 fender rail bolts/nuts. Discard bolts, but save (2) M8 nuts.
2. Install rack by inserting the longer supplied M8x45mm bolt through the front mounting hole of rack mount, one supplied washer, fender rail/frame and into the stock M8 nut retained from Step 1. Insert the shorter M8x20mm bolt through rear mounting hole of rack mount, one supplied washer and into fender rail/frame. **DO NOT TIGHTEN** at this time. Repeat on Right Side.
3. Align rack and tighten all bolts.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A

09/10

***Anything's Possible.***