



Items Supplied >

- 1 Sissy Bar with Pad
- 2 Mounting Brackets
- 2 8mm x 65mm Buttonhead Bolts
- 2 8mm x 90mm Butttonhead Bolts
- 4 8mm x 16mm Buttonhead Bolts
- 2 Short Spacers
- 2 Long Spacers

Application(s) >	www.cobrausa.com
SUZUKI M90	2009

Instruction Manual >

02-4842 / 02-5342

Your sissy bar will install in just a few minutes using common tools. Read all instructions completely.

- 1. Remove the left stock fender rail allen bolts from the fender rail. **NOTE:** Remove only one side at a time otherwise fender may fall resulting in possible damage to fender/paint. Install the left side sissy bar bracket with the stamped part number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M8 x 90mm bolt thru the bracket, longer spacer and into the fender rail. Insert the M8 x 65mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not tighten.** Repeat step for right side bracket.
- 2. Install the sissy bar between the brackets using the four (4) supplied 8mm x 16mm buttonhead bolts.
- 3. Make sure sissybar is aligned properly and tighten all hardware, torque the bolts installed in the fender rail to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A
03/09

Anything's Possible.

COBRA

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Sunnlied >

- 1 Sissy Bar with Pad
- 2 Mounting Brackets
- 2 8mm x 65mm Buttonhead Bolts
- 2 8mm x 90mm Butttonhead Bolts
- 4 8mm x 16mm Buttonhead Bolts
- 2 Short Spacers
- 2 Long Spacers

Annlication(s) >

www.cobrausa.com

SUZUKI M90

2009

Instruction Manual >

02-4842 / 02-5342

Your sissy bar will install in just a few minutes using common tools. Read all instructions completely.

- 1. Remove the left stock fender rail allen bolts from the fender rail. **NOTE:** Remove only one side at a time otherwise fender may fall resulting in possible damage to fender/paint. Install the left side sissy bar bracket with the stamped part number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M8 x 90mm bolt thru the bracket, longer spacer and into the fender rail. Insert the M8 x 65mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not tighten.** Repeat step for right side bracket.
- 2. Install the sissy bar between the brackets using the four (4) supplied 8mm x 16mm buttonhead bolts.
- 3. Make sure sissybar is aligned properly and tighten all hardware, torque the bolts installed in the fender rail to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.