

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar
- 2 - Brackets
- 4 - 8mm x 16mm Button Head Cap Screws
- 4 - 8mm x 45mm Button Head Cap Screws
- 4 - 4 Spacers

Application(s) >

Kawasaki VN1600A 03-08

Instruction Manual >

02-4961/02-5461/02-5961

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the (2) middle and (2) forward bolts from each stock fender rail.
2. Install left sissy bar bracket with the stamped number facing inward and align front hole of bracket with the front hole of the fender rail. Install 8mm x 45mm button head allen screws provided and place spacer provided between bracket and fender rail. Install another bolt and spacer in the same manner into the rear hole.
3. Install the sissy bar between the brackets using the (4) 8mm x 16mm button head bolts provided.
4. Tighten all hardware, torque the bolts in the fender rail to factory torque specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A
04/11

Anything's Possible.®

COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar
- 2 - Brackets
- 4 - 8mm x 16mm Button Head Cap Screws
- 4 - 8mm x 45mm Button Head Cap Screws
- 4 - 4 Spacers

Application(s) >

Kawasaki VN1600A 03-08

Instruction Manual >

02-4961/02-5461/02-5961

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the (2) middle and (2) forward bolts from each stock fender rail.
2. Install left sissy bar bracket with the stamped number facing inward and align front hole of bracket with the front hole of the fender rail. Install 8mm x 45mm button head allen screws provided and place spacer provided between bracket and fender rail. Install another bolt and spacer in the same manner into the rear hole.
3. Install the sissy bar between the brackets using the (4) 8mm x 16mm button head bolts provided.
4. Tighten all hardware, torque the bolts in the fender rail to factory torque specifications.

****Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019

REV. A

04/11

Anything's Possible.®