

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Supplied >

- 1 SISSY BAR WITH PAD
- 2 MOUNTING BRACKETS, LEFT & RIGHT
- 2 M8 X 40mm BUTTONHEAD BOLTS
- 2 M8 X 50mm BUTTTONHEAD BOLTS
- 4 M8 X 16mm BUTTONHEAD BOLTS
- 4 CHROME SPACERS

Application(s) >

KAWASAKI VN1700 CLASSIC

2009-2013

www.cobrausa.com

Instruction Manual >

02-4965 / 02-5465 / 02-5965

Your sissy bar will install in just a few minutes using common tools. Read all instructions completely.

- 1. Remove the left stock fender rail buttonhead bolts from fender rail. **NOTE:** Remove only one side at a time otherwise fender may fall resulting in possible damage to fender/paint. Install the left side sissy bar bracket, with the stamped part number facing inward, by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M8 x 50mm bolt thru the bracket, spacer and into the fender rail. Insert the M8 x 40mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not fully tighten.** Repeat step for right side bracket.
- 2. Install the sissy bar between the brackets using the four (4) supplied 8mm x 16mm buttonhead bolts.
- 3. Make sure sissybar is aligned properly and tighten all hardware securely, torque the bolts installed in the fender rail to factory specifications.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

Items Supplied >

- 1 SISSY BAR WITH PAD
- 2 MOUNTING BRACKETS, LEFT & RIGHT
- 2 M8 X 40mm BUTTONHEAD BOLTS
- 2 M8 X 50mm BUTTTONHEAD BOLTS
- 4 M8 X 16mm BUTTONHEAD BOLTS
- 4 CHROME SPACERS

Application(s) >

KAWASAKI VN1700 CLASSIC

2009-2013

www.cobrausa.com

Instruction Manual >

02-4965 / 02-5465 / 02-5965

Your sissy bar will install in just a few minutes using common tools. Read all instructions completely.

- 1. Remove the left stock fender rail buttonhead bolts from fender rail. **NOTE:** Remove only one side at a time otherwise fender may fall resulting in possible damage to fender/paint. Install the left side sissy bar bracket, with the stamped part number facing inward, by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M8 x 50mm bolt thru the bracket, spacer and into the fender rail. Insert the M8 x 40mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not fully tighten.** Repeat step for right side bracket.
- 2. Install the sissy bar between the brackets using the four (4) supplied 8mm x 16mm buttonhead bolts.
- 3. Make sure sissybar is aligned properly and tighten all hardware securely, torque the bolts installed in the fender rail to factory specifications.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.