



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 2 - Spacers, Short
- 2 - Spacers, Long
- 4 - M8 x 55mm Buttonhead Bolts
- 4 - M8 x 16mm Buttonhead Bolts

Application(s) >

HONDA VLX 600 1998 & UP

Instruction Manual >

02-4601/02-5101/02-5601

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets on each side with one short supplied spacer at the front and one long supplied spacer at the rear of each bracket between the bracket and the fender rail and secure using the four supplied (4) M8 x 55mm Button Head bolts, do not tighten completely.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 16mm Button Head bolts then tighten all hardware.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
03/07

Anything's Possible.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

www.cobrausa.com

Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 2 - Spacers, Short
- 2 - Spacers, Long
- 4 - M8 x 55mm Buttonhead Bolts
- 4 - M8 x 16mm Buttonhead Bolts

Application(s) >

HONDA VLX 600 1998 & UP

Instruction Manual >

02-4601/02-5101/02-5601

Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar.

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets on each side with one short supplied spacer at the front and one long supplied spacer at the rear of each bracket between the bracket and the fender rail and secure using the four supplied (4) M8 x 55mm Button Head bolts, do not tighten completely.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 16mm Button Head bolts then tighten all hardware.

** Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019 REV. A
03/07

Anything's Possible.