

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

## Items Supplied >

- 1 - Sissy Bar with Pad
- 2 - Brackets
- 2 - 8mm x 65mm Buttonhead Bolts
- 2 - 8mm x 90mm Buttonhead Bolts
- 4 - 8mm x 20mm Buttonhead Bolts
- 2 - Small Spacers (.375"); 2 - Large Spacers (.500")

## Application(s) >

www.cobrausa.com

Suzuki Boulevard M109R 2006 - 2014

## Instruction Manual >

02-7845

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. NOTE: Install one side at a time**

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M8 x 90mm bolt thru the bracket, longer spacer and into the fender rail. Insert the M8 x 65mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not tighten**
2. Repeat step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four (4) supplied M8mm x 20mm buttonhead bolts
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019 REV. A  
11/08

***Anything's Possible.®***

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

## Items Supplied >

- 1 - Sissy Bar with Pad
- 2 - Brackets
- 2 - 8mm x 65mm Buttonhead Bolts
- 2 - 8mm x 90mm Buttonhead Bolts
- 4 - 8mm x 20mm Buttonhead Bolts
- 2 - Small Spacers (.375"); 2 - Large Spacers (.500")

## Application(s) >

Suzuki Boulevard M109R 2006 - 2014

## Instruction Manual >

02-7845

**Your sissy bar will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new sissy bar. NOTE: Install one side at a time**

1. Remove the stock fender rail allen bolts from the fender rail. Install the left side sissy bar bracket with the stamped number facing inward by aligning the front hole of the bracket with the front hole of the fender rail and insert the supplied M8 x 90mm bolt thru the bracket, longer spacer and into the fender rail. Insert the M8 x 65mm bolt thru the bracket, spacer and into the rear hole of the fender rail. **Do not tighten**
2. Repeat step 1 for the right side bracket.
3. Install the sissy bar between the brackets using the four (4) supplied M8mm x 20mm buttonhead bolts
4. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019  
11/08

REV. A

**Anything's Possible.®**