

tems Supplied >	Application(s) >
I - Sissy Bar w/pad 2 - Brackets	Kawasaki Vulcan 1500 D/E/N 1996 - 2008
4 - 8mm x 20mm Buttonhead Bolts	
Instruction Manual >	02-7940 / 02-8940
′our sissy bar will install in just a few minutes using ompletely before installing your new sissy bar.	g common tools. Read all instructions carefully and
. Remove the two (2) rear bolts on each fender rai	il, first on the right side.
 Install the brackets with the bent portion (part num Brackets will mount on the outside of fender rail. 	mber) toward the inside using the stock bolts and tighten. Repeat on left side.
 Install the sissy bar to the brackets using the sup torque the bolts installed in the fender rail to factor 	pplied 8mm x 20mm bolts and tighten. Tighten all hardware, ory specifications.
	ile riding. Please never operate your motorcycle while under new look of your motorcycle and please ride safely.
CUMENT NO. 0019 REV. A	
//08	Anything's Possib
CORRA	alma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016
COBRA 23801 E. La Pa	www.cobrausa.

- completely before installing your new sissy bar. 1. Remove the two (2) rear bolts on each fender rail first on right side.
- 2. Install the brackets with the bent portion (part number) toward the inside using the stock bolts and tighten. Brackets will mount on the outside of fender rail. Repeat on left side.
- 3. Install the sissy bar to the brackets using the supplied 8mm x 20mm bolts and tighten. Tighten all hardware, torque the bolts installed in the fender rail to factory specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.