

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

## Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - Spacers
- 4 - M10 x 50mm Buttonhead Bolts
- 4 - M8 x 20mm Buttonhead Bolts

## Application(s) >

[www.cobrausa.com](http://www.cobrausa.com)

- |                     |              |
|---------------------|--------------|
| HONDA SPIRIT 750 C2 | 07-09, 12-14 |
| HONDA PHANTOM 750   | 2010-2019    |

## Instruction Manual >

02-8611B

**Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 20mm Button Head bolts then tighten all hardware.

**To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.**

**\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**

# COBRA®

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180, Fax. 714.692.5016

[www.cobrausa.com](http://www.cobrausa.com)

## Items Supplied >

- 1 - Sissy Bar w/pad
- 2 - Brackets
- 4 - Spacers
- 4 - M10 x 50mm Buttonhead Bolts
- 4 - M8 x 20mm Buttonhead Bolts

## Application(s) >

- |                     |              |
|---------------------|--------------|
| HONDA SPIRIT 750 C2 | 07-09, 12-14 |
| HONDA PHANTOM 750   | 2010-2019    |

## Instruction Manual >

02-8611B

**Read all instructions carefully and completely before installing your new sissy bar.**

1. Remove the stock fender rail bolts one side at a time.
2. Install the brackets with the supplied spacers and any stock washers between the bracket and the fender rail and secure using the four supplied (4) M10 x 50mm Button Head bolts, do not tighten completely.
3. Install the sissy bar to the brackets using the four (4) supplied M8 x 20mm Button Head bolts then tighten all hardware.

**To clean your black accessory use a liquid based soap detergent, such as dishwashing soap applied with a soft cloth and rinse with clean water. Note: Avoid abrasive cleaning methods such as granular or dry cleansers, simple green, Scotch-Brite or steel wool pads. Abrasives may breach the coating and shorten life.**

***\*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.***

DOCUMENT NO. 0019  
04/17

REV. A

**Anything's Possible.®**