

Items Supplied >

1 – Chrome Hub Cover

Application(s) >

Suzuki Volusia 800 01-04
Suzuki Boulevard M50 05-14
Suzuki Boulevard C50 05-14

Instruction Manual >

05-5328

Page 1 of 1

Read all instructions carefully before installing your new Cobra® product!

1. Support the motorcycle so that the front wheel is free off of the ground.
2. Loosen the front axle pinch bolts.
3. Remove the front brake caliper and pull it out of the way. (Do not pull the front brake level while the caliper is removed, this will make it difficult to reinstall the caliper later.)
4. Remove the front axle and pull off the front wheel.
5. Remove the axle spacer on the opposite side of the brake disk. Next install the hub cover in place of the axle spacer.
6. Reinstall the wheel, hub cover, and axle. Tighten the axle and pinch bolts to factory procedure and torque specifications. Improper reinstallation may result in the front suspension forks binding.
7. Install the front brake caliper and tighten all the bolts to factory recommended torque specifications.
8. Pump the front brake lever until the lever has a solid constant feel, when pulled. Check fluid level to be certain it is at proper operating level.

*** Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.**