

Items Supplied >

- 1 Left Floorboard Assembly W/Mount
- 1 Right Floorboard Assembly W/Mount

Application(s) >

www.cobrausa.com

HONDA VALKYRIE 97-03 HONDA VALKYRIE TOURER 97-00 HONDA VALKYRIE INTERSTATE 97-01

Instruction Manual >

06-3640/06-4640

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Boulevard Products Floorboards

- 1. Remove your original passenger footpeg mounts (with footpegs still attached) from the frame.
- 2. Install the Cobra passenger floorboard assemblies in the stock passenger mount location using the original bolts. Tighten the bolts to factory torque specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

05/01 REV. A

Anything's Possible.

COBRA

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

Items Sunnlied >

- 1 Left Floorboard Assembly W/Mount
- 1 Right Floorboard Assembly W/Mount

Annlication(s) >

www.cobrausa.com

HONDA VALKYRIE 97-03 HONDA VALKYRIE TOURER 97-00 HONDA VALKYRIE INTERSTATE 97-01

Instruction Manual >

06-3640/06-4640

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new Boulevard Products Floorboards

- Remove your original passenger footpeg mounts (with footpegs still attached) from the frame.
- 2. Install the Cobra passenger floorboard assemblies in the stock passenger mount location using the original bolts. Tighten the bolts to factory torque specifications.
- * Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.