



Items Supplied >

- 2 Floorboard Assemblies with Mounts
- 2 M8 x 40mm Hex Bolts
- 4 Flat Washers
- 2 M8 Nylock Nuts

Application(s) >

Suzuki Boulevard C90 05-09

Instruction Manual >

06-3840/06-4840

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

- 1. Remove your original passenger foot pegs from their mounts.
- 2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied M8 bolts, washers and nylock nuts.
- 3. Check to make sure that the bolts are tight prior to riding the motorcycle.
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A. 03/05

Anything's Possible.

www.cobrausa.com

www.cobrausa.com

**COBRA** 

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

## Items Sunnlied >

- 2 Floorboard Assemblies with Mounts
- 2 M8 x 40mm Hex Bolts
- 4 Flat Washers
- 2 M8 Nylock Nuts

Annlication(s) >

Suzuki Boulevard C90 05-09

## Instruction Manual >

06-3840/06-4840

Your passenger floorboards will install in just a few minutes using common tools. Read all instructions carefully and completely before installing your new passenger floorboards.

- 1. Remove your original passenger foot pegs from their mounts.
- 2. Install the passenger floorboard assemblies in the stock passenger foot peg location using the supplied M8 bolts, washers and nylock nuts.
- 3. Check to make sure that the bolts are tight prior to riding the motorcycle.
- \* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.

DOCUMENT NO. 0019 REV. A 03/05