

23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

Items Supplied >

- 2 Floorboard Assemblies with Mounts
- 2 5/64 x 1/2" Cotter Pins

Application(s) >	www.cobrausa.com
YAMAHA RAIDER	2008-2018

Instruction Manual >

06-4265

Read all instructions carefully and completely before installing your new passenger floorboards.

- 1. Remove cotter pin from retaining pin on front foot peg
- 2. Remove foot peg retaining pin, spring and foot peg from pivot.
- 3. Replace foot peg with new Cobra Floorboard and reinstall retaining pin and spring.
- 4. Install new supplied cotter pin thru Floorboard retaining pin and bend accordingly.
- 5. Repeat on opposite side.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

Items Supplied >

2 - Floorboard Assemblies with Mounts

2 - 5/64 X 1/2" Cotter Pins

Application(s) >	www.cobrausa.com
YAMAHA RAIDER	2008-2018

Instruction Manual >

06-4265

Read all instructions carefully and completely before installing your new passenger floorboards.

- 1. Remove cotter pin from retaining pin on front foot peg
- 2. Remove foot peg retaining pin, spring and foot peg from pivot.
- 3. Replace foot peg with new Cobra Floorboard and reinstall retaining pin and spring.
- 4. Install new supplied cotter pin thru Floorboard retaining pin and bend accordingly.
- 5. Repeat on opposite side.

*Cobra® recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.