

## Items Supplied >

- 1 - Black Mounting Bracket with hardware
- 2 - 8mm Nuts
- 1 - Front Heat Shield w/clamps
- 1 - Rear Heat Shield w/clamps

## Tools Required >

HONDA SPIRIT 1100 97-07

## Instruction Manual >

1370SC

Page 1 of 1

**PRIOR TO INSTALLATION, MAKE SURE YOUR STOCK GASKETS ARE IN GOOD SHAPE. IF YOU HAVE ANY DOUBTS AS TO THEIR CONDITION, REPLACE THEM.**

1. Remove stock exhaust system.
2. Install supplied mounting bracket to stock exhaust mounting tabs (bolts) using the 2 supplied 8mm nuts, leave the front nut loose, you will remove it on line 4. Note: Bracket arm should face toward rear of motorcycle. **DO NOT TIGHTEN.**
3. Install rear Boulevard Muffler first. If head pipe alignment in cylinder is a problem rotate supplied muffler flange 180° for better fit.
4. Install front Boulevard Muffler. Muffler bolts through bottom front mounting hole on supplied bracket. Front 8mm nut will need to be removed for this.
5. Tighten mounting bracket then, tighten exhaust bracket. Check for proper fit and alignment.
6. Install the front and rear full-length heat shields using the supplied hose clamps, Be careful not to scratch your chrome during installation of these heat shields.

NEED HEATSHIELD PLACEMENT DRAWING

**IMPORTANT:** It is recommended that you re-jet your bike with a Cobra Jet Kit, available from Cobra part #92-1270.

Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause discoloration. Due to fluctuations in carburetor settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*