

Items Supplied >

- 1 – FRONT MUFFLER ASSEMBLY
- 1 – REAR MUFFLER ASSEMBLY
- 4- 1/4" X 3/4" HEX FLANGED BOLTS

NOTE: MUFFLER INLET GASKETS CANNOT BE REUSED. NEW GASKETS (HD PN# 65900017) MUST BE PURCHASED BEFORE INSTALLATION.

Application >

HARLEY SOFTAIL:	
FLHC/FLHCS HERITAGE CLASSIC	2018
FLDE DELUXE	2018

Instruction Manual >

6048

Page 1 of 2

*****NOTE: MUFFLER INLET GASKETS CANNOT BE REUSED. NEW GASKETS (HD PN# 65900017) MUST BE PURCHASED BEFORE INSTALLATION.*****

Read all instructions carefully and completely before installing your new slip-on mufflers.

1. Remove the front (lower) muffler first. Loosen the muffler clamp and remove the two bolts on the muffler mount. Then slide the muffler backward off of the headpipe. Save the muffler clamp as it will be reused.
2. Remove the rear (top) muffler the same way.
3. Position the stock clamps with hex head as shown in **Figure 1** and slide them onto the slip-on mufflers.
4. Install new muffler inlet gaskets into the muffler inlets. See **Figure 1**. **NOTE:** MUFFLER INLET GASKETS CANNOT BE REUSED. NEW GASKETS (HD PN# 65900017) MUST BE PURCHASED BEFORE INSTALLATION.





FIGURE 1

5. Slide the rear (top) muffler onto the head pipe first, then the front (bottom) muffler second, until the mounting holes align. See **Figure 2**. **NOTE: THE MUFFLER WITH THE COBRA LOGO IS THE REAR (TOP) MUFFLER.**
6. Fasten the mufflers using the supplied 1/4" x 3/4" hex flanged bolts in the same manner as stock but **do not tighten**. See **Figure 2**. Verify that the gap, where the mufflers meet the stock heat shields, is similar to the gap the stock mufflers allotted.
7. Check all clearances and alignments then tighten the clamps. (NOTE: The muffler clamps should be flush with the end of the muffler when tightened. See **Figure 3**. If the muffler clamps are slid backward past the slots on the muffler slip the clamps will not tighten the mufflers properly).
8. Tighten the mounting bolts to factory specifications.
9. **IMPORTANT:** Before starting your engine remove all fingerprints from chrome with a quality wax or chrome polish. Failure to do so can cause chrome discoloration. Due to fluctuations in fuel delivery settings, timing, etc., Cobra Engineering does not warrant against chrome discoloration.
10. Check the tightness of the button head bolts securing the core/tip to each muffler after the first ride, 100 miles, and every 500 miles after that.

Continued on Page 2

DISCLAIMER: NOT LEGAL FOR SALE OR USE IN CALIFORNIA ON ANY POLLUTION CONTROLLED MOTOR VEHICLES.



SUPPLIED 1/4" X 3/4"
HEX FLANGED BOLTS

FIGURE 3

NOTE: SOFTAIL HERITAGE CLASSIC SHOWN.
MUFFLER POSITION VARIES DEPENDING ON
MODEL.

STOCK MUFFLER
CLAMP




FIGURE 4

IMPORTANT: To achieve optimum performance from your new mufflers it is suggested that you install a Cobra Fi2000® Digital Fuel Processor.

DISCLAIMER: NOT LEGAL FOR SALE OR USE IN CALIFORNIA ON ANY POLLUTION CONTROLLED MOTOR VEHICLES.