



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

#### Items Supplied >

- 1 – Plated Left Board Assembly
- 1 – Plated Right Board Assembly
- 2 – Flat Washers

#### Application(s) >

FLSTF,FLSTS,FLSTC,FLT,FLHR,FLHT,FLHTC,FLHTCU

#### Instruction Manual >

606-4100

**Please read all instructions thoroughly before installing your new floorboards**

1. Remove the stock front floorboards and save the hardware for latter use.
2. Place the supplied flat washers onto (2) of the stock bolts removed in step 1.
3. Mount the Cobra floorboards using the stock hardware, the bolts with the flat washer will be used on the rear mounting position of each floorboard.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A  
09/02

**Anything's Possible.**



23801 E. La Palma Ave., Yorba Linda, Ca 92887 Ph. 714.692.8180 Fax. 714.692.5016

www.cobrausa.com

#### Items Supplied >

- 1 – Plated Left Board Assembly
- 1 – Plated Right Board Assembly
- 2 – Flat Washers

#### Application(s) >

FLSTF,FLSTS,FLSTC,FLT,FLHR,FLHT,FLHTC,FLHTCU

#### Instruction Manual >

606-4100

**Please read all instructions thoroughly before installing your new floorboards**

1. Remove the stock front floorboards and save the hardware for latter use.
2. Place the supplied flat washers onto (2) of the stock bolts removed in step 1.
3. Mount the Cobra floorboards using the stock hardware, the bolts with the flat washer will be used on the rear mounting position of each floorboard.

*\* Cobra recommends you always wear a helmet while riding. Please never operate your motorcycle while under the influence of alcohol and/or drugs. Enjoy the new look of your motorcycle and please ride safely.*

DOCUMENT NO. 0019REV. A  
09/02

**Anything's Possible.**